

**56162-BK-MMO-010/11023**

NEXCOM

**0910-LP-264-7800**

**TECHNICAL MANUAL  
FOR  
LAUNDRY PRESS  
MODEL 3516 VSNE**

FORENTA, INC.

PO BOX 607

2300 W. ANDREW JOHNSON HWY.

MORRISTOWN, TENNESSEE 37814

CONTRACT # N00024-85-H-8197



THIS PUBLICATION IS REQUIRED FOR OFFICIAL USE OR FOR ADMINISTRATIVE OR OPERATIONAL PURPOSES. DISTRIBUTION IS LIMITED TO U.S. GOVERNMENT AGENCIES ONLY. OTHER REQUESTS FOR THIS DOCUMENT MUST BE REFERRED TO: COMMANDING OFFICER, NAVAL SHIP WEAPON SYSTEMS ENGINEERING STATION, CODE L700, PORT HUENEME, CA 93043-5000.

PUBLISHED BY DIRECTION OF COMMANDER, NAVAL SEA SYSTEMS COMMAND

**FOR OFFICIAL USE ONLY**

**1-APR-1989**



0910LP2647800

LIST OF EFFECTIVE PAGES

Date of original and change pages are:

original 0 . . . 1-APR-1989

Total number of pages in this publication is 20 consisting of the following:

Page No.	*Change No.	Page No.	*Change No.
Title and A . . . . .	0	4-5/4-6 . . . . .	0
Chg Record-1/(CR-2 Blank)0		4-7/(4-8 blank) . . . . .	0
Fwd-1/(Fwd-2 blank) . . . . .	0	5-1/5-2 . . . . .	0
A&PR-1/(A&PR-2 blank) . . . . .	0	6-1/6-2 . . . . .	0
Safety-1/(Safety-2 blank)0		6-3/(6-4 blank) . . . . .	0
i/ii . . . . .	0	7-1/7-2 . . . . .	0
1-1/1-2. . . . .	0	7-3/7-4 . . . . .	0
2-1/2-2. . . . .	0	7-5/7-6 . . . . .	0
3-1/3-1. . . . .	0	7-7/7-8 . . . . .	0
4-1/4-2. . . . .	0		
4-3/4-4. . . . .	0	TMDER (3)	

NOTE

On a changed page, the portion of the text affected by the latest change is indicated by a vertical bar in the outer margin of the page. Changes to drawings are indicated by miniature pointing hands.

\*Zero in this column indicates an original page.

## CHANGE RECORD

Change No.	Date	Title and/or Brief Description	Signature of Validating Officer

Change Record/(Change Record-blank)

FOREWORD

Ships, training activities, supply points, depots, Naval Shipyards and Supervisors of Shipbuilding and Repair are requested to arrange for the maximum practical use and evaluation of NAVSEA technical manuals. All errors, omissions, discrepancies, and suggestions for improvement to NAVSEA technical manuals shall be reported to the Commanding Officer, Naval Ship Weapon Systems Engineering Station (code 5H00), Port Hueneme, CA 93043 on NAVSEA Technical Manual Deficiency/Evaluation Report, NAVSEA Form 9086/10. To facilitate such reporting, 3 copies of NAVSEA Form 9086/10 are included at the end of each bound part of each technical manual. All feedback comments will be thoroughly investigated and originators will be advised of action resulting therefrom. Extra copies of NAVSEA Form 9086/10 (S/N0116-LF-090-8651) may be requisitioned from the Naval Publications and Forms Center (NPFC), Philadelphia, PA 19120.

APPROVAL AND PROCUREMENT RECORD

APPROVAL DATA FOR: NAVSEA S6162-BK-MMO-010/11023  
Technical Manual  
Laundry Press, Electrically Heated  
Trouser Topping, Double  
Model 3516VSNE

APPROVAL AUTHORITY: NAVAL SHIP SYSTEMS ENGINEERING STATION  
PHILADELPHIA, PA 19112-5083

LETTER SERIAL: 032E/469 dated 1 JUN 1989

CONTRACT NUMBER	SHIP APPLICABILITY	QUANTITY OF MANUALS	QUANTITY OF EQUIPMENT	REPAIR YARD
--------------------	-----------------------	---------------------------	-----------------------------	----------------

REMARKS:

CERTIFICATION:

DATE: 11 May 89

IT IS HEREBY CERTIFIED THAT NAVSEA S6162-BK-MMO-010/11023  
TO BE PROVIDED UNDER CONTRACT NUMBER N00024-85-H-8197 HAS  
BEEN APPROVED BY THE APPROVAL DATA SHOWN ABOVE.

Don Stevens  
Northwest Marine Iron Works  
5555 N. Channel  
Portland, OR 97217

A&PR-1/(A&PR-2 blank)

## SAFETY SUMMARY

### GENERAL SAFETY NOTICES

The following general safety notices supplement the specific warnings and cautions appearing elsewhere in this manual. They are recommended precautions that must be understood and applied during operation and maintenance of the equipment covered herein. Should situations arise that are not covered in the general or specific safety precautions, the commanding officer or other authority will issue orders as deemed necessary to cover the situation.

### DO NOT REPAIR OR ADJUST ALONE

Under no circumstances should repair or adjustment of energized equipment be attempted alone. The immediate presence of someone capable of rendering aid is required. Before making adjustments, be sure to protect against grounding. If possible, adjustments should be made with one hand, with the other hand free and clear of equipment. Even when power has been removed from equipment circuits, dangerous potentials may still exist due to retention of charges by capacitors. Circuits must be grounded and all capacitors discharged prior to attempting repairs.

### TEST EQUIPMENT

Make certain test equipment is in good condition. If a test meter must be held, ground the case of the meter before starting measurement; do not touch live equipment or personnel working on live equipment while holding a test meter. Some types of measuring devices should not be grounded; these devices should not be held when taking measurements.

### INTERLOCKS

Interlocks are provided for safety of personnel and equipment and should not be battle shorted or otherwise modified except by authorized maintenance personnel. Do not depend solely upon interlocks for protection. Whenever possible, disconnect power at power distribution source.

TABLE OF CONTENTS

<u>SECTION</u>	<u>PAGE</u>
Table of Contents	i
List of Illustrations	ii
1. Introduction/Specifications	1-1 to 1-2
2. Installation	2-1 to 2-2
3. Operating Instructions	3-1 to 3-3
4. Maintenance	4-1 to 4-7
5. Troubleshooting	5-1 to 5-2
6. Illustrations	6-1 to 6-3
7. Parts Listing & Parts Drawings	7-1 to 7-8

LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Description</u>	<u>Page</u>
1	Front View	1-1
2	Specification Detail Drawing	1-2
3	Air Supply Connection	2-1
4	Pressure Adjustment	3-2
5	2 Hand Safety Control	4-1
6	Heating Element Replacement	4-3
7	Padding Arrangement	4-4
8	Preventative Maintenance	4-7
9	Detail Line Drawing	6-1
10	Air Flow Diagram	6-2
11	Electrical Diagram	6-3
12	Parts Drawing, Left Side	7-3
13	Parts Drawing, Right Side	7-4
14	Parts Drawing, Air Strainer	7-5
15	Parts Drawing Activating Cylinder	7-5
16	Parts Drawing, Air Regulator	7-5
17	Parts Drawing, Valve	7-5
18	Parts Drawing, Cylinder Assy	7-6
19	Parts Drawing, Padding	7-6

LIST OF TABLES

<u>TABLE</u>	<u>Description</u>	<u>Page</u>
5-1	Trouble Shooting	5-1



MODEL 3516 VSNE  
PANTS TOPPER AND SMALL  
WEARING APPAREL PRESS




Figure 1. Front View

### 1.1 INTRODUCTION

The Model 3516 Pant Topper Press is a laundry press mounted on a Forenta Small V. Press Base. This press is used for small wearing apparel such as shirts, blouses, pullovers, pants, pant tops, jackets, etc.

The press is pneumatically operated with two hand control for closing the head and a Safety/Release Bar that surrounds the head for opening the head by lifting the bar.

For the best results in press usage, keep padding and cover in good condition, replacing as needed. In turn follow maintenance instructions carefully and make any necessary adjustments as called for. The Model 3516 is one of the fastest operating laundry presses in the world.

## 1.2 SPECIFICATIONS

Width, Overall.	. . . . .	43
Depth, Overall.	. . . . .	.35 1/8"
Height, Overall	. . . . .	58
Air pressure.	. . . . .	.68 lbs.
Air Consumption	. . . . .	.1/6 CFM
Air Inlet	. . . . .	.3/8 NPT

Electrical Requirements:  
440 volts, 3600 watts, 4.7 amps  
3ph, 60 HZ

Domestic Shipping  
Weight (approx.). . . . .470 lbs.






FIGURE 2. Specification Line Drawing

## 2.0 INSTALLATION

### 2.1 UNCRATING

Uncrate machines carefully and check for concealed damage. Remove from base and move to approximate location before removing any of the holding blocks that are used for shipment. It is best to leave these in position until machine has been connected and the air turned on.

If any damage caused by shipping is found, it should be reported to the transportation company and a claim filed by you.

CAUTION: DO NOT PUSH, PULL OR ATTACH RIGGING TO THE HEAD, BUCK OR LEVERAGES.

### 2.2 COMPRESSED AIR CONNECTIONS

NOTE: Air lines should be blown out thoroughly before connecting to the machine. This will help prevent debris from damaging valves and stopping up lines.

All air-operated machines have 3/8" connection at rear (see specifications). We recommend air filters on each machine to prevent dirt and scale from getting into the valves and air cylinders. If start and stop type of compressor is used, valve should be set so air does not go below 75 pounds. If constant running compressor is used with unloading valve, set between 70 and 80 pounds.




Fig 3. RECOMMENDED AIR SUPPLY PIPING ILLUSTRATION

NOTE: If other equipment require higher pressures, it is alright to set the compressor higher since all Forenta equipment has its own pre-set internal regulator.

A shut-off valve should be installed at each machine so that it can be serviced, if necessary, without shutting down the rest of the unit.

## 2.0 INSTALLATION

### 2.3 ELECTRICAL CONNECTIONS

Always use a qualified electrician in wiring any Forenta press to insure compliance with all local and national codes.

On electrically-heated models, the thermostats are rated to carry a heavier load than shown on the nameplate mounted on the frame of the machine. Do not allow your electrician to become confused and insist on heavier wiring because of the higher readings on the thermostat nameplate.

A main cut-out switch is recommended to control the electricity to the unit. Do not use the thermostat to shut off the machine. The thermostat should be carefully set at the proper temperature for the best operation and left at that setting.

### 3 OPERATING INSTRUCTIONS

#### 3.1 TEMPERATURE

The on-off switch is located in the center front of the press. It should be switched to the on position to start the heat up of the press. The thermostat for the top pressing head should be set between 300° F and 320° F. This should be sufficient temperature to allow for proper drying without scorching the garments. The bottom buck thermostat should be set between 260° F and 275° F for the proper temperature to keep the padding dry. Allow the press 15 to 20 minutes to heat up to the proper pressing temperature.

#### SCORCHING

Temperature only is not necessarily the cause. Be sure your clothes are properly rinsed -- because soap will cause discolorations under heat.

#### 3.2 TWO HAND CONTROL/SAFETY CONTROL BAR OPERATION

Operation of the two-hand control system is accomplished by depressing and holding the two buttons on the front of the table. This will bring the head down into pressing position. The machine still retains the safety feature of the control bar. If the bar hits some obstruction on the down stroke, the head will release. To raise the head at the end of the cycle, lift slightly on the control bar.

#### 3.3 PRESSING INSTRUCTION

The use of the utility or apparel pressing surface frequently depends on the operator. The buck and head are tapered to allow small garments to be dressed. The broader base of the buck, as well as the length of the pressing surface can be used for creasing and pressing pant tops. The operator must determine the best position for the garment to get the best results.

#### 3.4 PRESSURE ADJUSTMENTS

Adjust the press to meet your needs. Thicker garments, different kinds of materials, number of layers, etc., all have a bearing on the amount of pressure and length of time needed by the press. The Pressure Control knob is located under the front table in the center of the machine.

## OPERATING INSTRUCTION (CONT)

## PRESSURE ADJUSTMENTS CONTINUED

NOTE: This knob adjusts the position of the pressure arm roller in the cam at the rear top portion of the press. When the machine is in the pressing position, this roller should be  $\frac{3}{4}$ " to 1" from the top of the cam. Turn clockwise to bring the roller higher in the cam slot. Turn counterclockwise to stop the roller at a lower point in the cam slot. The padding may need to be replaced if there is a lack of pressure at this point. Good pressing results are only possible with proper padding and pressure. (Refer to the "Maintenance" section in this manual for padding instructions.) Caution: Do not adjust so that roller hits the top of the cam slot.





Figure 4  
PRESSURE ADJUSTMENT ILLUSTRATION

#### 4. MAINTENANCE

NOTE: It is recommended that no adjustments be made on this press without first carefully reading the following instructions and without eliminating any outside causes for trouble, such as a low air pressure.

##### 4.1 TWO-HAND SAFETY CONTROL OPERATION

The two hand control on the front of the table closes the head. The Safety Control Bar has no affect on the closing of the head. However, the Control Bar does release the head with a gentle lift on the Control Bar. This bar should always be positioned about 2" below the top of the buck when the head is down. If adjustments are necessary (refer to illustration below), they can be made easily by loosening the Collars "A" on Shaft "B" and moving the Safety Control Bar to the proper position. When this position is attained, the Collars must then be adjusted against the Springs "C" to hold the Safety Control Bar in position and return to position after it has been actuated. Cam "D" must be adjusted so that it opens Valve "E" with the slightest lift on the Safety Control Bar. When Valve "E" is opened, it will exhaust all air from the press.



2" Position of control bar with head closed.

NOTE: The Safety Control Bar should always be adjusted so it is about 2" below the top of the buck when the head is in the pressing position.

NOTE: Adjusting screw (1) and (2) should be set so that the valve lever bottoms out on the stop bumper, just before the stem on the valve bottoms out.

CAUTION: The stems on valve (1) and (2) should never bottom out.

Fig.5 TWO-HAND SAFETY CONTROL ILLUSTRATION

## MAINTENANCE (Cont.)

## 4.2 AIR STRAINER

Remove screen from air strainer (figure 10, piece 7) and clean as required.

## 4.3 IF THE HEAD DOES NOT OPEN WIDE

This usually indicates weak springs. Tighten each of the large vertical springs on the rear of the press uniformly.

## 4.4 DOUBLE-ACTING SHOCK ABSORBER (snubber)

If the head goes up so hard at the top that it bounces back down, this usually indicates the Shock Absorber needs adjustment. If the head slams against the buck on the closing and proper operation cannot be secured by adjusting the Air Control Valve (see "Head Closing Speed Adjustment"), the Shock Absorber may need setting. This is accomplished by adjusting screws at each end of the shock cylinder. Loosen lock nut slightly before adjusting, and then tighten securely to prevent oil leakage. Adjust rear screw to control open snubbing action. Turning screw clockwise increases snubbing action and counterclockwise decreases snubbing action.

Adjust screws only about one turn at a time. A supply of oil should stay in the shock reservoir at all times. If oil has to be added, use SAE #10 non-detergent oil.

NOTE: If shock is very old and adjusting does not seem to make it work properly, drain the oil out through the adjusting screws and replace with SAE #20 non-detergent oil. If this does not help, then replace the shock absorber.

## 4.5 AIR CYLINDERS

If the main pressure cylinder or any air cylinder develops air leaks, the O-ring must be replaced. When removing O-ring from the piston, be careful not to nick on edge of the groove. The O-ring can usually be slipped off by pressing the ring between thumb and forefinger and sliding toward one side to create looseness so that it can be pulled off with the other hand. Clean the piston and cylinder wall. Replace the O-ring using a liberal amount of plastilube grease. It is also advisable to use a new base gasket when re-assembling the cylinder. A light film of grease can be applied to the piston rod to prevent rust and reduce friction.

NOTE: Plastilube grease may be obtained from Forenta.

CAUTION: DO NOT PUT OIL IN CYLINDERS.

## 4.6 IF PRESSURE ARM JUMPS AFTER HEAD CLOSES

First, be sure cylinder is properly lubricated and not binding. Next, set pressure adjustment by turning knob as instructed in the Operating Instruction section. If the trouble still persists, this usually indicates too much down-snubbing action. If the snubber takes hold too soon and before the head reaches the buck, it may cause excessive air pressure to build up in the cylinder and as soon as the pressure lever goes from low pressure to high



## MAINTENANCE (cont)

## If Pressure Arm Jumps Just After Head Closes (Cont)

pressure position, it will move very rapidly three or four inches, rather than moving slowly into high pressure position. Adjust as instructed under "Double-Acting Shock Absorbers" in Maintenance section. Head springs that are set too tight will also cause this.

## 4.7 LUBRICATION

All bearings are packed with grease and should last for years. However, grease fittings have been provided at all bearing points and should be greased at least every six months.

NOTE: Refer to "Preventative Maintenance Servicing Schedule" section.

## 4.8 HEATING ELEMENT REPLACEMENT

To replace a head heating element: Disconnect power to the machine. Disconnect wires from the heating element. Loosen the hold down nuts. Slide the element and hold down strip out from between the head plates. Reverse this procedure to replace the element making sure the hold down strip is in place as shown in the illustration. Make sure the wire terminals have adequate clearance from any metal parts.

To replace a buck heating element: Disconnect power to the machine. Remove all padding. Remove the buck face plate. Disconnect wires from the heating element. Bend the element hold downs to remove the element. Reverse this procedure to replace the element.





Figure 6

## 4.9 HEAD CLOSING SPEED ADJUSTMENT

Adjusting Valve (figure 10, piece 9) can be turned clockwise to slow head movement down and turned counter-clockwise to make the head close faster. The Valve should be adjusted so the head comes down down rapidly and smoothly without slamming on the buck.

#### 4.10 AIR PRESSURE

Regulator (figure 10, piece 8) should be set at 68 PSI.

#### 4.11 PADDING


The padding must be maintained properly to assure a quality finish. The buck liner goes against the bare buck. The mesh pad is placed on the liner. A piece of 20 oz. nylon flannel goes on top of the mesh. A larger piece of 20 oz. punched nylon flannel is placed on top of this flannel. This flannel should be large enough to tuck under the buck so as to keep the outer cover from coming into contact with the bare buck. The outer cover goes on last and is tied on with a draw string. Springs also are used underneath the buck to help secure the cover and keep it tight.

The flannel should be checked about every 4 weeks. If it has become hard and brittle, it should be replaced. This flannel must stay soft and have some bounce-back to it in order to get a good press. If it is not replaced when necessary, continuous pressing will cause it to deteriorate as it is compressed against the mesh pad.

The mesh pad may last for one, two, or three years, more or less, depending on how much the press is used and depending on how well the flannel described above is maintained.

The outer cover need be replaced only when it shows signs of wear or deterioration. The outer cover should be washed when it becomes soiled.

NOTE: The padding, as a whole, must have some downward compression when the head comes into pressure, and upward expansion when the head is raised.



PADDING ILLUSTRATION

Figure 7

#### 4.12 CARE OF PRESS HEAD

Clean all pressing surfaces with EZ-OFF while heads are hot. If scouring is needed, use a copper mesh scouring pad. This should be done daily or as often as needed. Apply Paraffin wax, or Hot Head Press Lube twice daily. This will help prevent starch build up.

#### 4 PREVENTATIVE MAINTENANCE SCHEDULE

**CAUTION:** Do not add oil to the air system or air cylinders.

DAILY:

1. Apply paraffin wax or HOT-HEAD PRESS LUBE to all polished pressing surfaces.
2. As needed clean all polished pressing surfaces with EZ-OFF while heads are hot. Do not use any abrasive that will damage the polished surfaces.
3. Drain air filters in the supply line to the machine.

Every three(3) months:

(Numbers in parenthesis refer to figure 8)

1. Check for steam and air leaks (any leaks should be repaired).
2. Insure the sight glass (1) on the snubber is filled with SAE-10 non-detergent oil.
3. Apply a light coat of grease or oil to the piston rod (2) to prevent rust build-up.
4. Apply a light coat of grease or oil to the stem valves (3) and (4).
5. Remove strainer on air separator (7), clean and reinstall.
6. Check the air gauge connected to the pressure regulator (8) to insure it is set to the recommended pressure as specified in the instruction manual.
7. Apply a light film of grease to the cam roller guide slot (5).
8. Inspect the buck cover and flannels (6). Replace if worn or frayed.
9. Check the control system to insure the machine is functioning properly.

## PREVENTATIVE MAINTENANCE SERVICING SCHEDULE (CONT')

10. Check the electrical controls to insure the on/off switch is functional, the thermostats are functional, and the "HEAT ON" pilot lights are functional.
11. Check the mechanical action of the machine to insure that it is working smoothly with no erratic action. Make adjustments or repairs as necessary.

Every six (6) months:

(see attached drawing)

1. Grease all grease fittings. (There are 13 grease fittings.)
2. Inspect buck padding (6). Replace if worn or frayed.
3. Remove cam roller bearings and repack with grease. (Requires approximately 1 hour.)

Every twelve (12) months:

(see attached drawings)

1. Inspect buck padding (6) and replace as needed.

Pre-Installation/Storage Maintenance:

No servicing of this type of laundry press is required during pre-installation storage or in service storage as long as the press is kept in dry storage.

## PREVENTATIVE MAINTENANCE SERVICING SCHEDULE (CONT)




Figure 8

PREVENTATIVE MAINTENANCE SERVICING ILLUSTRATION

5. TROUBLESHOOTING

TABLE 5-1

PROBLEM	POSSIBLE CAUSE	REMEDY
Press Closes Slowly	Air pressure low	Set air reg. #8 to 68lbs.
	Piston ass'y in reg. #8 defective	Replace piston ass'y.
	Air metering valve #9 closed.	Open until head closes at correct speed.
	Air valve #3 not opening.	Adjust per instruction under maintenance.
	O-Ring leaking in main cylinder.	Replace O-Ring.
Press closes too fast	Air pressure above 68 lbs.	Turn air regulator to 68 lbs.
	Air metering valve open too much.	Adjust metering valve.
	Snubber out of oil.	Fill with #10 non-detergent oil.
	Air regulator piston ass'y leaking.	Replace piston ass'y.
Press closes with a thump	Snubber out of adjustment. (NOTE) To lessen snubbing action, turn front bolt one turn at a time counter-clockwise until the desired results are obtained.	Adjust snubber.
	Air metering valve #9 closed too tight.	Open valve #9.
Head slams up when press released.	Snubber out of oil.	Fill with #10 wt. non-detergent oil.
	Snubber out of adjustment.	Adjust snubber.
Air leaks through small hole in top of regulator	Diaphragm leaking.	Replace diaphragm.
Continuous air leak through bleed hole in cylinder wall or top when cylinder is under pressure.	Cut or worn o-ring.	Replace O-Ring. See instructions in Maintenance Section.

TABLE 5-1 (CONT)

PROBLEM	POSSIBLE CAUSE	REMEDY
Air pressure on press builds up to main line pressure	Piston assembly in air regulator not seating.	Replace piston ass'y.
Drop in pressure more than 4 to 5 lbs. when press is operated.	Partial stoppage in air supply line to press.	Blow lines and regulator out.
	Dirty regulator and carbon build-up in regulator air passages.	Clean regulator.
	Piston assembly in bottom of air regulator leaking.	Replace piston assembly.
	Screen in Air Strainer #7 stopping up.	Clean screen.
Air pressure cannot be regulated by adjusting screw in top of air regulator	The spring in top of regulator is broken or rusted, causing loss of tension.	Replace spring.
	Diaphragm leaking.	Replace diaphragm.
Heads do not completely open or drop somewhat after opening	Not enough head spring tension to hold the head at a full open position.	Add enough spring tension to hold the head at a full open position.
Air leaking around stem of valve.	Small o-ring on stem leaking.	Replace "O" Ring.
No heat on head.	Hd. thermostat defective.	Replace thermostat.
	Hd. element burned out.	Replace element.
	Circuit breaker kicked out or fuse blown.	Reset breaker or fuse.
Buck not heating.	Buck thermostat defective	Replace thermostat.
	Buck element burned out.	Replace element.
	Circuit breaker kicked out or fuse blown	Reset circuit breaker or fuse.

## 3516 VSNE

## 6. ILLUSTRATIONS





Figure 9. Detail Line Drawing





- s - Supply air direction
- x - Exhaust air direction
- 1 - Right operating valve
- 2 - Left operating valve
- 3 - Cylinder supply valve
- 4 - Cylinder exhaust valve
- 5 - Head locking valve
- 6 - Air pressure gauge
- 7 - Air strainer
- 8 - Air pressure regulator
- 9 - Head closing speed valve
- 10 - Head closing cylinder
- 11 - Head closing actuating cylinder
- 12 - Head release valve

### AIR FLOW DIAGRAM

Supply valve 3 is actuated when the two-hand buttons pressed. It supplies air to the head closing cylinder. Valve 4 is the exhaust valve. It exhausts all air from the machine when the head is opened.



7.1 Parts List

Fig-Item	Part #	Description	Qty
12- 1	15739	Shaft for head mount to pressure roller	1
12- 2	15740	Shaft, rocker arm	2
12- 3	A-656	Cam for head pressure	1
12- 4	29441	Safety kick-off Rod	1
12- 5	A-627	Cylinder Assembly, 2.75 ID main (consists of parts in Figure 18)	1
12- 6	16511	Kick-off rod spring	2
12- 7	15767-79	Bushing 3/8 x 1/2 x 1/2	2
12- 8	29415	Safety kick off cam	1
12- 9	15941	Kick-off spring	1
12-10	A-5822	Valve lever	1
12-11	A-5821	Activating cylinder assembly (consists of parts in Figure 15)	1
12-12	A-782	Snubber, left hand	1
12-13	15100	Valve, .25 stem-operated "whistle valve" (consists of parts in Figure 17)	2
12-14	16371	Metering valve	1
12-16	16386	Knob	1
12-17	15115-4	Guard rail	1
12-40	28034-3	Air valve	2
13-18	A-1872	Pressure lever service assy w/bearings/ spacer/grease fittings. Consists of:	1
	15748	Spacer for bearing, long, 13/16"ODx3"	1
	A-1818	Bearing assembly	2
	A-4160	Lever weldment	1
13-19	30630-1	440V/600W Head element	4
13-20	30761-1	440V/600W Buck element	2
13-21	A-652	Bar connecting snubber to cam	1
13-22	30934	Off/On switch	1
13-23	A-6445	320 degree F head thermostat	1
13-24	30933	Pilot light	2
13-25	A-6446	275 degree F buck thermostat	1
13-26	16079-1	Gauge, air pressure	1
13-27	16048	Regulator, 1/4" (consists of parts in Fig 16)	1
13-28	30932	Contacto	2
13-29	15803	Spring, piston return (fork to frame)	2
13-30	A-1648	Spring, head lift service assy with inserts. Consists of:	2
	15786	#3 Head lift spring	1
	16041	Spring insert	2
13-31	16610	Air Strainer (consists of parts in Fig 14)	1
13-32	15810	Shaft, cylinder pivot	1
13-33	26125	Oiler	1
13-34	15746	Shaft, pressure adjusting, 1" x 3.5"	1
13-35	A-794	Rod, pressure adjusting	1
13-36	A-653	Pressure link service assembly w/ bearings & grease fittings. Consists of:	1
	15270	Bearing, race	2
	15271	Bearing, needle	2
	16366	Grease fitting	2
	17061	Pressure link, small v	1

## 7.1 Parts List (continued)

Fig-Item	Part #	Description	Qty
13-37	A-4259	Fork casting for piston rod	1
13-38	15744	Shaft, cam to pressure line, 1" x 2"	1
13-39	A-1871	Spring hanger assembly. Consists of:	2
	A-651	Hanger weldment	1
	A-1818	Bearing assembly consisting of:	1
	16391	Needle bearing	1
	16397	Race	1
13-40	28034-3	Air valve	2
13-41	A-1820	Roller service assembly to follow pressure cam. Consists of:	1
	16556	Roller	1
	A-1819	Bearing assembly	1
13-42	15743	Shaft, cam roller	1
13-43	15741	Shaft, spring hanger	1
13-44	15048	Spring	1
13-45	A-4160	Pressure lever	1
14-31A	none	Body	1
14-31B	none	Screen	1
14-31C	none	Gasket	1
14-31D	none	Plug	1
15-11A	15097-6	O-ring	1
15-11B	A-2569	Cylinder tube	1
15-11C	15381	Cylinder top	1
15-11D	A-5681	Piston rod weldment	1
16-27A	21660	Spring	1
16-27B	21661	Gasket for diaphragm	1
16-27C	21662	Diaphragm	1
16-27D	21665	Piston	1
16-27E	21666	Spring for piston	1
16-27F	27559-6	Gasket	1
17-13A	16707	Lock nut	1
17-13B	16511	Spring	1
17-13C	16606	Seat Holder	1
17-13D	15923	Disc	1
17-13E	27121-6	Screw	1
17-13F	27121-2	Stem	1
17-13G	15097-5	O-ring, 5/16	1
18- 5A	15117	Base casting	1
18- 5B	A-1598	Piston and Rod	1
18- 5C	15097-4	O-ring, 2.75	1
18- 5D	18262-6	Tube for cylinder, 2.75	1
18- 5E	15403	Gasket	1
18- 5F	15116	Top casting	1
19-46	30921	Buck liner	1
19-47	30920	Monel buck pad	1
19-48	29335	Small (bottom) flannel	1
19-49	29336	Large (top) flannel	1
19-50	29334	Buck cover w/spring	1
none	16359-1	Plastilube grease (cartridge)	
none	K-152	Shock absorber oil (quart)	




Figure 12, Parts Drawing, Left Side


PARTS ILLUSTRATION  
RIGHT SIDE VIEW

Figure 13. Parts Drawing, Right Side




Figure 14. Parts Drawing, Air Strainer




Figure 15. Parts Drawing  
Activating Cylinder




Figure 16. Parts Drawing, Regulator




Figure 17. Parts Drawing, Valve




Figure 18. Parts Drawing, Cylinder Assembly




Figure 19. Parts Drawing, Padding



7.2 PARTS BY OTHER VENDORS

Forenta Part #	Fig#-Item	Vendor Name (See pg 7-8 for address)	Vendor Part #
1503	18-5E	Cooper Mfg. Co.	Forenta #15403
15097-4	18-5C	General Rubber & Plastic	Precision 332-7507
15097-6	15-11A	General Rubber & Plastic	Precision 115-7507
15100	12-13	United Brass Works	43-1/4
15786	13-30	Kokomo Spring Corp.	Forenta #15786
15803	13-29	Pepka Spring Company	Forenta #15803
15941	12- 9	Kokomo Spring Corp.	Forenta #15941
16048	13-27	A.W.Cash Valve Mfg.Co.	A-31S
16079-1	13-26	Dresser Industries	2" 1000
16371	12-14	Parker Brass Products	NV108P-4
16610	13-31	United Brass Works	200-3/8x24 Mesh
28034-3	13-40	Air-Mite Devices, Inc.	MV2-C
29334	19-50	Quality Products Company	Forenta #29334
29335	19-48	Quality Products Company	Forenta #29335
29336	19-49	Quality Products Company	Forenta #29336
30630-1	13-19	Acra Electric Company	Forenta #30630-1
30761	13-20	CEM Electric Co., Inc.	Forenta #30761-1
30920	19-47	Resillo Press Pad Co.	Forenta #30920
30921	19-46	Resillo Press Pad Co.	Forenta #30921
30932	13-28	Allen-Bradley Company	500-TOB93
30933	13-24	Robert Shaw Controls	Z60100-0100
30934	13-22	OEM Controls	NN-16
A-782	12-12	Hydraulic Products Corp.	Forenta #A-782

7.3 VENDOR LIST & ADDRESSES

Acra Electric Company  
3801 North 25th Avenue  
Schiller Park, IL 60176

Air-Mite Devices, Inc.  
4739 W. Montrose Avenue  
Chicago, IL 60641

Allen-Bradley Company  
Industrial Control Division  
Dwight Place  
Fairfield, NJ 07006

A.W.Cash Valve Mfg.Co.  
PO Box 191  
Decatur, IL 62525

CEM Electric Co. Inc.  
1747 Industrial Drive  
Greenwood, IN 46142

Cooper Mfg. Co.  
409 South First Street  
Marshalltown, IA 50158

Dresser Industries  
250 E. Main Street  
Stratford, CT 06497

General Rubber & Plastic  
4785 Mendel Court  
Atlanta, GA 30336

Hydraulic Products Corp.  
613 West 11th Street  
Erie, PA 16501

Kokomo Spring Corp.  
Kokomo, IN 46901

OEM Controls  
10 Controls Drive  
Shelton, CT 66484

Parker Brass Products  
6796 Jimmy Carter Blvd.  
Norcross, GA 30071

Pepka Spring Company  
810 S. Waugh  
Kokomo, IN 46901

Quality Products Company  
4248 North Elston Avenue  
Chicago, IL 60618

Resilio Press Pad Co.  
6950 N. Central Park Avenue  
Chicago, IL 60645

Robert Shaw Controls  
Yongswood, PA 15697

United Brass Works  
Randleman, NC 27317